



## IMPORTANT ASSEMBLY INSTRUCTION

To ensure proper bolt alignment:

- Hand-thread ALL bolts first.
- Fully tighten ONLY after all bolts are in.
- Do NOT use an electric screwdriver to fully tighten the first bolt before others are inserted.
- Use only the provided hex-head Allen wrench bit when using an electric screwdriver. Do not use personal drill bits.
- Set electric screwdriver to **Driver Mode + Low Torque**.
- Start slow; keep screw straight. Do NOT over-tighten.
- Keep fingers clear, wear protection, avoid impact drivers.